

NAUGAHYDE

 There is only one true Naugahyde and it's proudly made in the USA.

[PRODUCTS](#) > [PROMOTIONAL ITEMS](#) > [COLOR CO-ORDINATES](#) > [NAUGAHYDE FAQ'S](#) > [CLEANING & CARE](#) > [HOME](#)
[CORPORATE INFORMATION](#) > [NAUGA HISTORY](#) > [NAUGAHYDE NEWS](#) > [CONTACT US](#) > [DISCLAIMERS](#) > [SITE MAP](#)

Cleaning Naugahyde®

Advanced BeautyGard™ Protective Finish

Cleaning is a breeze with Naugahyde brand fabric and its Advanced BeautyGard protective finish. While staining and soiling exposures are common to upholstery fabrics, most stain and soiling may be removed by using the simple cleaning methods that follow:



For Light soiling:

1. A solution of 10% household liquid dish soap with warm water applied with a soft damp cloth will remove most soiling.
2. If necessary, a solution of liquid cleanser and water applied with a soft bristle brush. Wipe away the residue with a water-dampened cloth.

For Heavier soiling not solved by above method:

1. Dampen a soft white cloth with lighter fluid (naphtha) and rub gently. Rinse with a water-dampened cloth.

NOTE: Use **extreme** caution with this method. Complete only in a well-ventilated area and away from any open flame.

NOTE: You should **try this method on an inconspicuous spot** before using it on the original stain/soiling.

For the most difficult stains not removed by the above methods:

1. Dampen a soft white cloth with a solution of household bleach (sodium hypochlorite); 10% bleach, 90% water.
2. Rub gently.
3. Rinse with a water-dampened cloth to remove bleach concentration.
4. If necessary, allow a 1:10 diluted bleach solution to puddle on the affected area or apply with a soaked cloth for approximately 30 minutes. Rinse with a water-dampened cloth to remove any remaining bleach concentration.

NOTE: You should **try this method on an inconspicuous spot** before using it on the original stain/soiling.

Note

To restore luster, a light coat of spray furniture wax can be used. Apply for 30 seconds and follow with a light buffing using a clean white cloth.

Antimicrobial

Naugahyde with Advanced BeautyGard provides outstanding protection in difficult medical and health care environments.

Contains agents effective against bacterial and fungal microorganisms.

Please Review Carefully

CAUTION: Should you desire to use other cleaning methods, carefully try them in an inconspicuous area to determine potential damage to the material. Never use harsh solvents or cleaners which are intended for industrial applications. To clean stained or soiled areas, a soft white cloth is recommended. Avoid use of paper towels.

CAUTION: Cleaning products may be harmful/irritating to your skin, eyes, etc. Use protective gloves and eye protection. Do not inhale or swallow any cleaning product. Protect surrounding area/clothing from exposure. Use in a well ventilated area. Follow all product manufacturer's warnings. Naugahyde cannot be held responsible for damage or injuries resulting from the use or misuse of cleaning products.

**NAUGAHYDE® the original vinyl coated fabric.
All the rest are imitations!**

*Uniroyal Engineered Products LLC Naugahyde National Sales Office > 1001 North Main Street, Suite 6 > Nappanee, Indiana 46550-1038 > USA
Call Toll-Free: 877-628-4248 ext. 932 > Phone: 574-773-2282 ext. 932 > Fax: 574-773-5984 > naugahyde@naugahyde.com*